





### Disassembly instruction



A		1
	Teak wood	
B		2
	Teak wood	
C		2
	Teak wood	
D		1
	Teak wood	

E		8
	Brass bolt	
F		14
	Steel	

#### STEP 1

Remove the 8 brass bolt on the right and left side

#### STEP 2

Remove the 14 screws on the cushion box top

#### STEP 3

Remove all parts from the cushion box