





Disassembly instruction



A		1
	Teak wood	
B		4
	Teak wood	
C		1
	Teak wood	
D		4
	Teak wood	

E		4
	Brush bolt	
F		24
	Steel	

STEP 1

Turn the table upside down

STEP 2

Remove the 4 bolts and 24 screws on the table legs and table leg supports

STEP 3

Remove the table legs and table leg support